


LOLLIBLY

Their World, Your Peace of Mind



MEADOW PLAYPEN

www.lollibly.com

f @ @ @lollibly

Meadow Playpen

Their World, Your Peace of Mind




Stable & Secure

Reinforced 4-point stability ensures maximum stability and durability



Inspiring Independent Play

Panels come with 6cm-gaps for a wider field of vision, easy parental supervision, and easy grip to facilitate early standing and walking



Baby-Safe & Eco-Friendly

Crafted from 100% baby-safe HDPE to ensure a non-toxic, child-safe environment for play and growth. Safe for babies in the teething phase



Hassle-Free Assembly

Snap-on connectors for quick and effortless setup or adjustments







Customisable To Fit Any Space

Adjustable panels and accessories to create the perfect play space

Playmats Configuration:

40cm 50cm 80cm Gate



*Compatible with Lollyliby Big One Playmat



Things to Take Note:

- Assembly should be performed by adults only.
- Ensure all parts are kept and follow the instructions carefully to assist with future configurations of your playpen.
- Do not place or use the playpen on uneven surfaces or near stairs to avoid potential safety hazards.
- Keep the playpen away from direct sunlight or heat sources for extended periods to prevent damage or discolouration.
- Avoid using or storing the playpen on wet surfaces or in humid environments to prevent potential damage.


Product Care Instructions:

- Disassemble the playpen into its individual components.
- Using a damp cloth or sponge with mild soap, wipe down all parts of the playpen. Avoid using harsh chemicals or abrasive cleaners.
- Rinse thoroughly with clean water to remove any residue.
- Allow all components to air dry completely before reassembling.

Storage Instructions:


- Keep all parts and accessories in a dry, well-ventilated area, away from moisture and direct sunlight.
- Consider storing components in bags to prevent dust buildup or stains.
- Use labelled bags or containers to organise and easily locate parts when needed.
- Store your playpen indoors, away from extreme temperatures and high humidity.
- Do not stack the playpen or its components under heavy objects to prevent deformation or damage.

Overview of Parts




A (81cm)

x 1




B (81cm)

x 3



C (51cm)

x 4



D (41cm)

x 4



E2

x 8



E1

x 8



F2

x 4




F1

x 4



I

x 20



F2



E2




E1




I



F1



1




Indicates top of panel




Indicates bottom of panel


Attach the silicone anti-slip pads (I) to the protruding parts on the bottom of each panel.



Position panel A with the door side facing outward, before securing the panels together using connectors E1 and E2.






For right-angle connections, use connectors F1 and F2 to securely join the panels.






Repeat the steps above until the entire playpen is fully assembled.

How to Use the Door Lock:

*As the gate panel A is the same length as panel B, they can be positioned interchangeably.



To lock the door (when closed):
Pull the lever outward and turn it to the right.



To unlock the door (when open):
Pull the lever outward and turn it downward.

Flexi-frame Setup

Overview of Parts:


Additional Accessory
Sold Separately
Additional Accessory

Customise your playpen's shape with the Flexi-frame. This sturdy stand holds panels securely in place, giving you the flexibility to create the perfect layout for your space.




A

x 2




B

x 2



C

x 2




D

x 6




F

x 1




E


x 2




Instructions




Slide part A into the groove of part B.




Insert the assembled parts A and B into the grooves of the base plate C.




Use the mounting tool (F) to fasten the fixing screws (D) to the underside of the base plate C.



Slide the chosen panel into base C.



Secure the top using connector E.



Repeat these steps to attach the stands to both ends.

Their World, Your Peace of Mind



Inspiring Independent Play



Stable & Secure



Customisable To Fit Any Space



Hassle-Free Assembly



Baby-Safe & Eco-Friendly

www.lollibly.com

f @lollibly